


STEP 1

Place the frame on the ground. Two people hold the frame legs and spread it out to half its size.




STEP 2

Cover the top of the frame with the canopy sheet. Attach to the top of the frame by matching the velcro tape on the four corners of the sheet to the corresponding velcro on the frame corners.



STEP 3

Two people hold the 'X' truss on the opposite sides and expand it until it touches the eaves of the sheet.



STEP 4

Step on the leg pad and lift up the outer leg until the turn buttons lock. Repeat the process for the other legs.



STEP 5

Fold the corner eaves of the canopy sheet in half. Step on the leg pad and push the 'X' truss upward until the turn buttons on the leg locks into place. Repeat process for the other corners.



STEP 6

Unfold the corner eaves and tie the strings to the legs tightly. Raise the frame to the desired height by extending the telescopic legs. Use the stakes and ropes to hold down when windy.